

RH12437PP installation.

This is an aftermarket damper designed to have a slightly softer ride setting at slower speeds than the Bilstein damper.

Please note: This Shock Absorbers must be fitted with the dust cover up as per the direction arrow on the body of the shock absorber.

While it is possible to fit a rear shock absorber with the dust cover downward **it will not operate.**

Before fitting the shock absorber, turn it the right way up (dust cover to the top), and operate it a few times by hand to prime the damper, taking care not to over-compress so that the lip on the operating shaft does not pass into the seal in the shock absorber body. If you over-compress the shock absorber it will not return and oil will leak past the seal, invalidating the warranty.

Please note: This Shock Absorber must be fitted with the dust cover up as per the direction arrow on the body of the shock absorber.



