

# Flying Spares

## FITTING INFORMATION FOR THE DOOR SEALS ON ROLLS-ROYCE SILVER SHADOW & BENTLEY T MODELS

**Please note:** the original door seals were a continuous one piece seal. Our aftermarket version is a one piece seal that requires you to start feeding the seal from the right angle point on the door and finish with the two ends joining together underneath the centre of the door.

- 1- Locate the angled corner of the seal
- 2- Fit this corner section to the door frame first



- 3- Work the seal in to the frame in each direction from this corner until the two ends meet on the underside of the door frame.

