
INSTRUCTIONS SHEET FOR RH2714P



If you are working on the RAM upside down, the black seal will be visible